




EN

# Shupatto

## ○Specifications

Products	Size	Volume	Capacity	Material
Shupatto Compact Bag S	 30 cm / 11.8 in	7.5 L	3 kg / 6.6 lb	Polyester
Shupatto Compact Bag M	 35 cm / 13.8 in	15 L	5 kg / 11 lb	Polyester
Shupatto Compact Bag L	 50 cm / 19.7 in	40 L	15 kg / 33 lb	Polyester
Shupatto Compact Bag M (Recycled)	 35 cm / 13.8 in	15 L	5 kg / 11 lb	100% Recycled Polyester*

\*Excludes the tapes and buttons      Made in China

## ○How To Fold Shupatto


### • Shupatto Compact Bag S




Hold the tapes of both ends and ...



Pull




Fold in half twice




Roll it up to wrap the band around to hold it closed


### • Shupatto Compact Bag M / L




Hold the tapes of both ends and ...



Pull



Fold in half twice



Roll it up to close the button

## ○Precautions for use

- Children should not use this product without supervision.
- Do not hang this bag for too long, with heavy objects inside.
- This bag can be damaged when dragged or with sharp objects inside.
- Some color loss on this bag may be caused when it has just begun to be used and when contacting with wet objects.
- Do not use this product outside of intended purpose of use.

## ○Product Care

- Fold this bag down immediately after use.
- If the pleats do not fold in neatly, fold it after straightening the pleats along the pleat lines.
- Machine washable (Max. temp.: 30 degrees C)
- Do not use chlorine bleaches, fabric softeners, dryers or irons on this bag. Also, avoid soak washing.
- After washing, straighten the bag along the pleat lines and flat dry in an airy shade.